

## BTR 800 CHANNEL MAP

## F1 Band

Base Tx	16		17		18	
Bp Tx	482	488	488	494	494	500
	38		39		40	
	614	620	620	626	626	632

Pair Groups = 24 (12a + 12b)

Single Groups = 12

**NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

## F2 Band

Base Tx	16		17		18	
	482	488	488	494	494	500
Bp Tx	41		42		43	
	632	638	638	644	644	650

Pair Groups = 24 (12a + 12b)

Single Groups = 12

**NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

## F3 Band

Base Tx	16		17		18	
Bp Tx	482	488	488	494	494	500
	44		45		46	
	650	656	656	662	662	668

Pair Groups = 24 (12a + 12b)

Single Groups = 12

**NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

## F4 Band

Base Tx	16		17		18	
Bp Tx	482	488	488	494	494	500
	47		48		49	
	668	674	674	680	680	686

Pair Groups = 24 (12a + 12b)

Single Groups = 12

## **NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

### H1 Band

Base Tx	19	20	21																	
Bp Tx	500	506	506	512	512	518														
	38		39		40															
	614	620	620	626	626	632														

Pair Groups = 24 (12a + 12b)

Group	1a	1b	2a	2b	3a	3b	4a	4b	5a	5b	6a	6b	7a	7b	8a	8b	9a	9b	10a	10b	11a	11b	12a	12b
Tx	19	19	20	20	21	21	19	19	20	20	21	21	19	19	20	20	21	21	19	19	20	20	21	21
1	500.2	502.2	506.2	508.2	512.2	514.2	500.5	501.4	506.5	508.4	512.5	514.4	503.8	500.5	510.1	506.5	514.4	512.5	500.3	502.8	506.3	508.8	512.3	514.8
2	504.3	503.5	510.3	509.5	516.3	515.5	504.6	502.7	510.6	509.7	516.6	515.7	505.3	502.6	511.4	508.4	516.6	515.7	504	504.7	510	510.7	516	516.7
Rx	38, 39, 40	38, 39, 40	38, 39, 40	38, 39, 40	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	38, 39	
1	614.2	614.2	614.2	614.2	614.2	614.2	614.5	614.5	614.5	614.5	614.5	614.5	614.5	614.5	620.5	620.5	620.5	620.5	614.1	614.1	614.1	614.1	614.1	
2	614.7	614.7	614.7	614.7	614.7	614.7	614.8	614.8	614.8	614.8	614.8	614.8	614.8	614.8	620.8	620.8	620.8	620.8	614.4	614.4	614.4	614.4	614.4	
3	616.5	616.5	616.5	616.5	616.5	616.5	615.3	615.3	615.3	615.3	615.3	615.3	615.3	615.3	622.7	622.7	621.9	621.9	621.3	621.3	614.9	614.9	614.9	614.9
4	619	619	619	619	619	619	617.6	617.6	617.6	617.6	617.6	617.6	617.6	617.6	624	624	624	624	623.6	623.6	617.2	617.2	617.2	617.2
5	622	622	622	622	622	622	619.6	619.6	619.6	619.6	619.6	619.6	619.6	619.6	626.3	626.3	626	626	625.6	625.6	618.9	618.9	618.9	618.9
6	625.5	625.5	625.5	625.5	625.5	625.5	622.1	622.1	622.1	622.1	622.1	622.1	622.1	622.1	628.3	628.3	628.5	628.5	628.1	628.1	619.8	619.8	619.8	619.8
7	626.7	626.7	626.7	626.7	626.7	626.7	623.3	623.3	623.3	623.3	623.3	623.3	623.3	623.3	630	630	630.8	630.8	629.3	629.3	626.5	626.5	626.5	626.5
8	630.4	630.4	630.4	630.4	630.4	630.4	624.8	624.8	624.8	624.8	624.8	624.8	624.8	624.8	630.8	630.8	631.6	631.6	630.8	630.8	629.5	629.5	629.5	629.5
9	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
10	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

Single Groups = 12

Group	13	14	15	16	17	18	19	20	21	22	23	24												
Tx	19	20	21	19	20	21	19	20	21	19	20	21												
1	502.5	507.7	514.5	502.4	508.4	514.4	502.4	508.4	514.4	502.4	508.4	514.4												
2	503.5	509.1	515.7	504.6	510.6	516.6	504.6	510.6	516.6	504.6	510.6	516.6												
Rx	38, 39, 40	38, 39, 40	38, 39, 40	38, 39, 40	38	38	39	39	39	39	40	40												
1	614.1	614.2	614.3	614.2	614.2	614.2	620.2	620.2	620.2	626.2	626.2	626.2	626.2											
2	614.5	614.7	614.7	614.7	614.7	614.7	620.7	620.7	620.7	626.7	626.7	626.7	626.7											
3	616.4	618.3	617	615.4	615.4	615.4	621.4	621.4	621.4	627.4	627.4	627.4	627.4											
4	619.8	619.5	619.5	618.1	618.1	618.1	624.1	624.1	624.1	630.1	630.1	630.1	630.1											
5	623.5	623.2	625	---	---	---	---	---	---	---	---	---	---											
6	624.9	626.1	626.7	---	---	---	---	---	---	---	---	---	---											
7	627.9	628.6	629.7	---	---	---	---	---	---	---	---	---	---											
8	629.1	631.6	631.6	---	---	---	---	---	---	---	---	---	---											
9	---	---	---	---	---	---	---	---	---	---	---	---	---											
10	---	---	---	---	---	---	---	---	---	---	---	---	---											

NOTES:

- 1) Groups 25 - 26 are user-programmable and are blank initially.
- 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
- 3) "---" = Blank
- 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

## H2 Band

Base Tx	19		20		21	
Bp Tx	500	506	506	512	512	518
	41		42		43	
	632	638	638	644	644	650

Pair Groups = 24 (12a + 12b)

Single Groups = 12

## **NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

### H3 Band

Base Tx	19		20		21	
Bp Tx	500	506	506	512	512	518
	44		45		46	
	650	656	656	662	662	668

Pair Groups = 24 (12a + 12b)

Single Groups = 12

## **NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

## H4 Band

Base Tx	19		20		21	
	500	506	506	512	512	518
Bp Tx	47		48		49	
	668	674	674	680	680	686

Pair Groups = 24 (12a + 12b)

Single Groups = 12

**NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

A2 Band

Base Tx	22		23		24	
Bp Tx	518	524	524	530	530	536
	41		42		43	
	632	638	638	644	644	650

Pair Groups = 24 (12a + 12b)

Single Groups = 12

## NOTES

- 1) Groups 25 - 26 are user-programmable and are blank initially.**
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.**
  - 3) "—" = Blank**
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.**

## BTR 800 CHANNEL MAP

A3 Band

Base Tx	22		23		24	
	518	524	524	530	530	536
Bp Tx	44		45		46	
	650	656	656	662	662	668

Pair Groups = 24 (12a + 12b)

Single Groups = 12

**NOTES:**

- Groups 25 - 26 are user-programmable and are blank initially.
  - The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - "—" = Blank
  - Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

A4 Band

Base Tx	22		23		24	
	518	524	524	530	530	536
Bp Tx	47		48		49	
	668	674	674	680	680	686

Pair Groups = 24 (12a + 12b)

Single Groups = 12

**NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

B3 Band

Base Tx	25		26		27	
Bp Tx	536	542	542	548	548	554
	44		45		46	
	650	656	656	662	662	668

Pair Groups = 24 (12a + 12b)

## Single Groups = 12

**NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

B4 Band

Base Tx	25		26		27	
Bp Tx	536	542	542	548	548	554
	47		48		49	
	668	674	674	680	680	686

Pair Groups = 24 (12a + 12b)

Single Groups = 12

**NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

B6 Band

Base Tx	25		26		27	
	536	542	542	548	548	554
Bp Tx	53		54		55	
	704	710	710	716	716	722

**NOTICE:**  
**This wireless microphone system cannot be operated in the United States or its territories, and is intended solely for export and use outside of the United States.**

## **NOTES:**

- Groups 25 - 26 are user-programmable and are blank initially.
  - The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - "--" = Blank
  - Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

C3 Band

Base Tx	28		29		30	
	554	560	560	566	566	572
Bp Tx	44		45		46	
	650	656	656	662	662	668

Pair Groups = 24 (12a + 12b)

Single Groups = 12

## **NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

C4 Band

Base Tx	28		29		30	
Bp Tx	554	560	560	566	566	572
	47		48		49	
	668	674	674	680	680	686

Pair Groups = 24 (12a + 12b)

Single Groups = 12

## **NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

## BTR 800 CHANNEL MAP

### C6 Band

Base Tx	28	29	30
	554	560	560
		566	566
Bp Tx	53	54	55
	704	710	710
		716	716
		722	722

#### NOTICE:

This wireless microphone system cannot be operated in the United States or its territories, and is intended solely for export and use outside of the United States.

Pair Groups = 24 (12a + 12b)

Group	1a	1b	2a	2b	3a	3b	4a	4b	5a	5b	6a	6b	7a	7b	8a	8b	9a	9b	10a	10b	11a	11b	12a	12b
Tx	28	28	29	29	30	30	28	28	29	29	30	30	28	28	29	29	30	30	28	28	29	29	30	30
1	554.2	556.2	560.2	562.2	566.2	568.2	554.5	555.4	560.5	562.4	566.5	568.4	557.8	554.5	564.1	560.5	568.4	566.5	554.3	556.8	560.3	562.8	566.3	568.8
2	558.3	557.5	564.3	563.5	570.3	569.5	558.6	556.7	564.6	563.7	570.6	569.7	559.3	556.6	565.4	562.4	570.6	569.7	558	558.7	564	564.7	570	570.7
Rx	53,54,55	53,54,55	53,54,55	53,54,55	53,54	53,54	53,54	53,54	53,54	53,54	53,54	53,54	54,55	54,55	54,55	54,55	54,55	54,55	53,55	53,55	53,55	53,55	53,55	53,55
1	704.2	704.2	704.2	704.2	704.2	704.2	704.5	704.5	704.5	704.5	704.5	704.5	710.5	710.5	710.5	710.5	710.5	710.5	704.1	704.1	704.1	704.1	704.1	704.1
2	704.7	704.7	704.7	704.7	704.7	704.7	704.8	704.8	704.8	704.8	704.8	704.8	710.8	710.8	710.8	710.8	710.8	710.8	704.4	704.4	704.4	704.4	704.4	704.4
3	706.5	706.5	706.5	706.5	706.5	706.5	705.3	705.3	705.3	705.3	705.3	705.3	712.7	712.7	711.9	711.9	711.3	711.3	704.9	704.9	704.9	704.9	704.9	704.9
4	709	709	709	709	709	709	707.6	707.6	707.6	707.6	707.6	707.6	714	714	714	714	713.6	713.6	707.2	707.2	707.2	707.2	707.2	707.2
5	712	712	712	712	712	712	709.6	709.6	709.6	709.6	709.6	709.6	716.3	716.3	716	716	715.6	715.6	708.9	708.9	708.9	708.9	708.9	708.9
6	715.5	715.5	715.5	715.5	715.5	715.5	712.1	712.1	712.1	712.1	712.1	712.1	718.3	718.3	718.5	718.5	718.1	718.1	709.8	709.8	709.8	709.8	709.8	709.8
7	716.7	716.7	716.7	716.7	716.7	716.7	713.3	713.3	713.3	713.3	713.3	713.3	720	720	720.8	720.8	719.3	719.3	716.5	716.5	716.5	716.5	716.5	716.5
8	720.4	720.4	720.4	720.4	720.4	720.4	714.8	714.8	714.8	714.8	714.8	714.8	720.8	720.8	721.6	721.6	720.8	720.8	719.5	719.5	719.5	719.5	719.5	719.5
9	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
10	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

Single Groups = 12

Group	13	14	15	16	17	18	19	20	21	22	23	24
Tx	28	29	30	28	29	30	28	29	30	28	29	30
1	556.5	561.7	568.5	556.4	562.4	568.4	556.4	562.4	568.4	556.4	562.4	568.4
2	557.5	563.1	569.7	558.6	564.6	570.6	558.6	564.6	570.6	558.6	564.6	570.6
Rx	53,54,55	53,54,55	53,54,55	53	53	53	54	54	54	55	55	55
1	704.1	704.2	704.3	704.2	704.2	704.2	710.2	710.2	710.2	716.2	716.2	716.2
2	704.5	704.7	704.7	704.7	704.7	704.7	710.7	710.7	710.7	716.7	716.7	716.7
3	706.4	708.3	707	705.4	705.4	705.4	711.4	711.4	711.4	717.4	717.4	717.4
4	709.8	709.5	709.5	708.1	708.1	714.1	714.1	714.1	720.1	720.1	720.1	720.1
5	713.5	713.2	715	---	---	---	---	---	---	---	---	---
6	714.9	716.1	716.7	---	---	---	---	---	---	---	---	---
7	717.9	718.6	719.7	---	---	---	---	---	---	---	---	---
8	719.1	721.6	721.6	---	---	---	---	---	---	---	---	---
9	---	---	---	---	---	---	---	---	---	---	---	---
10	---	---	---	---	---	---	---	---	---	---	---	---

#### NOTES:

- 1) Groups 25 - 26 are user-programmable and are blank initially.
- 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
- 3) "..." = Blank
- 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.

BTR 800 CHANNEL MAP | E88 Band

Base Tx	34		35		36	
Bp Tx	590	596	596	602	602	608
	14		15		16	
	470	476	476	482	482	488

Pair Groups = 24 (12a + 12b)

Single Groups = 12

**NOTES:**

- 1) Groups 25 - 26 are user-programmable and are blank initially.
  - 2) The BTR-800 band plan is the same as the BTR-700 except the BTR-800 transmitter 1 (Ch A) frequencies are not used.
  - 3) "—" = Blank
  - 4) Pair Groups are Intermodulation Coordinated. Example 1a, 1b may be used together.